

Encoding a Transceiver (SR-i500)

Note: Transceivers are programmed from the factory. Encoding is only necessary should the Transceiver loses its code and will not arm or disarm the security system, or for replacement

1. Unplug the Main Harness (closes to the side) from the MCM.
2. Plug in the MCM, the siren will chirp 2 times and the lights will flash 2 times.
Within 6 seconds turn ignition switch "ON" and "OFF" 3 times.
3. If the sequence is done correctly and within the time allowed , the siren will chirp 2 times and the lights will flash an additional 2 times to confirm that the system is in "Learn Mode"
4. Press and hold button # 1 for 5 seconds, system will chirp 2 times and the lights will flash 2 times to indicate that the MCM has learned the code.
5. The Transceiver echoes 4 chirps and the LCD displays [**LErn donE**] to confirm that the Transceiver is encoded.
6. Turn ignition "ON" and "OFF" to exit "Learn Mode"

Note: If you are encoding a second Transceiver repeat step number 4 for the second transceiver before moving to step number four.

